



- 1 Locate 2, 1/4-20 holes in chair frame.
- 2 Assemble Stand-off assembly.
- 3 Assemble two brackets as shown.
- 4 Attach bracket to chair, using the longer bolt through the two brackets at the bottom.
- 5 Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.
- 6 Attach mixed gas and scavenger hoses to back of the GCS.

