



- 1 Remove upholstery & locate existing hole in frame as shown.
- 2 Run bracket up between frame and shroud, placing the 1/4-20 post through the frame as shown. Tighten the lock nut & washer onto the post.
- 3 Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.
- 4 Attach mixed gas and scavenger hoses to back of the GCS.

