



- 1 Remove Seat Upholstery.
- 2 Remove side piece, patient left side.
- 3 Install bracket studs through side piece, Install inside plate with 2 nuts.
- 4 Assemble GCS with mixed Bag Tee and Scavenger to GCS bracket as shown.
- 5 Attach mixed gas and scavenger hoses to back of the GCS.

